2006-2008 ELECTRICAL

Relay and Control Unit Locations - Civic Hybrid

ENGINE COMPARTMENT



Fig. 1: Identifying Relay And Control Unit Locations - Engine Compartment
Courtesy of AMERICAN HONDA MOTOR CO., INC.

DASHBOARD


FRONT ACCESSORY POWER SOCKET RELAY
[Wire colors: BLU, WHT, BLK, and PUR]
CONSOLE ACCESSORY POWER SOCKET RELAY
[Wire colors: BLK, PUR, GRN, and YEL]
GAUGE CONTROL MODULE (SPEEDO)
GAGUE CONTROL MODULE (TACH)
POWER WINDOW RELAY
PGM-FI MAIN RELAY 2
STARTER CUT RELAY
MICU
UNDER-DASH FUSE/RELAY BOX
View of front side
View of rear side

Fig. 2: Identifying Relay And Control Unit Locations - Dashboard (1 Of 2)
Courtesy of AMERICAN HONDA MOTOR CO., INC.



Fig. 3: Identifying Relay And Control Unit Locations - Dashboard (2 Of 2)
Courtesy of AMERICAN HONDA MOTOR CO., INC.

REAR


MOTOR CONTROL MODULE (MCM) RELAY 2
Wire colors: ORN, GRN/YEL, PNK, and GRN/YEL
MOTOR CONTROL MODULE (MCM) RELAY 1
Wire colors: RED, BLU, PNK, and LT GRN
MOTOR CONTROL MODULE (MCM)
XM RECEIVER
('07-08 models with navigation)

Fig. 4: Identifying Relay And Control Unit Locations - Rear
Courtesy of AMERICAN HONDA MOTOR CO., INC.

DOOR

DRIVER'S DOOR



Fig. 5: Identifying Relay And Control Unit Locations - Driver Door
Courtesy of AMERICAN HONDA MOTOR CO., INC.

SEAT

FRONT PASSENGER'S SEAT

Fig. 6: Identifying Relay And Control Unit Locations - Front Passenger Seat
Courtesy of AMERICAN HONDA MOTOR CO., INC.